

VOGUE

Electric knife Sharpener

Instruction manual



**Model:
GD232-A**

Safety Tips

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components on this product.
- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - Fire Precautions
 - Wiring Regulations
 - Building Regulations
- DO NOT place hands near sharpening channels when in use.
- DO NOT sharpen scissors or any blade that does not fit freely in the sharpening channels.
- DO NOT place wet blades in the sharpening slots.
- DO NOT immerse the appliance in water.
- DO NOT attempt to sharpen blades thicker than 3mm.
- Suitable for indoor use only.
- Always switch off and disconnect the power supply to the appliance when not in use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.

- If the power cord is damaged, it must be replaced by a VOGUE agent or a recommended qualified technician in order to avoid a hazard.
- VOGUE recommends that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Insulation Continuity and Functional Testing.

Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your VOGUE product.

Pack Contents

The following is included:

- VOGUE electric knife sharpener
- Adapter
- Instruction manual


VOGUE prides itself on quality and service, ensuring that at the time of packaging the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your VOGUE dealer immediately.

Operation



Note: The VOGUE Knife Sharpener automatically adjusts to accommodate varying thickness of blade.



Sharpening Tips

- Apply light pressure to the blade when sharpening for best results.
- Pull the blade in a single, smooth motion.
- To sharpen the tip of the blade, pull the handle up at the end of the pulling motion.
- Always alternate between the left and right slots of any sharpening stage.



Note: Ensure that knife blades are clean and dry before sharpening.

Sharpening Stage 1

Use for blades with a very blunt edge.

1. Connect the sharpener to the mains power supply.
2. Turn the power switch to 'I'.
3. Hold the handle of the knife firmly and place the blade hilt in the left sharpening slot of Stage 1.
4. Apply enough pressure for the knife to make contact with the sharpening wheel.
5. Pull the blade back to the tip in a smooth motion. Do not twist or rock the blade.
6. Repeat this process for the right sharpening slot of Stage 1.



Note: As a guide, each pull for a 6 inch blade should take 2-3 seconds. An 8 inch blade should take 4 seconds and longer blades 6+ seconds.

Sharpening Stage 2

Use for honing a blade or to achieve a razor sharp edge after stage 1.


- Repeat steps 3-6 as above, using Sharpening Stage 2.



Note: 1-2 pulls on each side of stage 2 is normally sufficient, though more pulls will achieve a finer edge.

Cleaning, Care & Maintenance

- **Always turn off and disconnect the appliance from the power supply before cleaning.**
- Use soapy water and a damp cloth to clean the exterior of the appliance.
- Remove the sharpening head by turning clockwise. The covers of the sharpening wheels (1 & 2) can be removed by pushing the cover in at one end and lifting. Filings can then be emptied. Afterwards, assemble the appliance in the reverse order.



Troubleshooting

If your VOGUE appliance develops a fault, please check the following table before making a call to the Helpline.

Fault	Probable Cause	Solution
The unit is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug and lead are damaged	Call VOGUE agent or qualified Technician
	Power supply	Check power supply
	Internal wiring fault	Call VOGUE agent or qualified technician
The knife is not sharpening	Insufficient pressure applied to the knife	Apply more pressure to the knife
	Sharpening wheels are worn	Call VOGUE agent or qualified technician

Technical Specifications

Model	Voltage	Power	Weight	Dimensions h x w x d mm
GD232-A	100-240V~ 50/60Hz	18W	0.7Kg	220 x 78.5 x 81

Compliance

The product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.

VOGUE parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

VOGUE products have been approved to carry the following symbol:



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of VOGUE.

Every effort is made to ensure all details are correct at the time of going to press, however, VOGUE reserve the right to change specifications without notice.

DECLARATION OF CONFORMITY

• Conformiteitsverklaring • Déclaration de conformité • Konformitätserklärung • Dichiarazione di conformità •
• Declaración de conformidad • Declaração de conformidade

Equipment Type • Uitrustingstype • Type d'équipement • Gerätetyp • Tipo di apparecchiatura • Tipo de equipo • Tipo de equipamento		Model • Modèle • Modell • Modello • Modelo • Malli
Knife Sharpener		GD232 (-E & -A)
Application of Territory Legislation & Council Directives(s) Toepassings van Europese Richtlijn(en) • Application de la/des directive(s) du Conseil • Anwendbare EU-Richtlinie(n) • Applicazione delle Direttive • Aplicación de la(s) directiva(s) del consejo • Aplicação de directiva(s) do Conselho	Low Voltage Directive (LVD) - 2014/35/EU EN 60335-1: 2012 +A11:2014 EN 60335-2-14:2006 +A12:2016 EN 62233:2008 EN 62368-1:2014 +A11:2017 Electro-Magnetic Compatibility (EMC) Directive 2014/30/EU - recast of 2004/108/EC EN 55014-1:2017 EN 55014-2:2015 EN 55015:2013 +A:2015 EN 55024:2010 +A1:2015 EN 55032:2015 EN 55035:2017 EN 61000-3-2: 2014 EN 61000-3-3: 2013 EN 61547:2009 Restriction of Hazardous Substances Directive (RoHS) 2015/863 amending Annex II to Directive 2011/65/EU	Electrical Safety AS/NZS 60335.1:2011 +A1:2012 +A2:2014 +A3:2015 +A4:2017 AS/NZS 60335.2.14:2013 AS/NZS 61558.1:2008 +A1:2009 +A2:2015 AS/NZS 61558.2.16:2010 +A1:2010 +A2:2012 +A3:2014 Electromagnetic Compatibility AS/NZS CISPR32:2015 EN 55014-1:2017 EN 55014-2:2015 EN 61000-3-2: 2014 EN 61000-3-3: 2013
Producer Name • Naam fabrikant • Nom du producteur • Name des Herstellers • Nome del produttore • Nombre del fabricante • Nome do fabricante		Vogue

I, the undersigned, hereby declare that the equipment specified above conforms to the above Territory Legislation, Directive(s) and Standard(s).

Ik, de ondergetekende, verklaar hierbij dat de hierboven gespecificeerde uitrusting goedgekeurd is volgens de bovenstaande Richtlijn(en) en Standaard(en).

Je soussigné, confirme la conformité de l'équipement cité dans la présente à la / aux Directive(s) et Norme(s) ci-dessus

Ich, der/die Unterzeichnende, erkläre hiermit, dass das oben angegebene Gerät der/den oben angeführten Richtlinie(n) und Norm(en) entspricht.

Il sottoscritto dichiara che l'apparecchiatura di sopra specificata è conforme alle Direttive e agli Standard sopra riportati.

El abajo firmante declara por la presente que el equipo arriba especificado está en conformidad con la(s) directiva(s) y estándar(es) arriba mencionadas.

Eu, o abaixo-assinado, declaro que o equipamento anteriormente especificado está em conformidade com a(s) anterior(es) Directiva(s) e Norma(s)

Date • Data • Date • Datum • Data •
 Fecha • Data
 Signature • Handtekening •
 Signature • Unterschrift Firma •
 Firma • Assinatura

Full Name • Volledige naam • Nom et prénom • Vollständiger Name •
 Nome completo • Nombre completo •
 Nome por extenso

Position • Functie • Fonction •
 Position • Qualifica • Posición •
 Função

Producer Address • Adres fabrikant •
 Adresse du producteur • Anschrift des Herstellers • Indirizzo del produttore • Dirección del fabricante •
 Morada do fabricante

18TH November 2020

DocuSigned by:

Ashley Hooper
 B39382C9FD9C478...

Ashley Hooper

DocuSigned by:

Eoghan Donnellan
 D352874F7FAB460...

Eoghan Donnellan

DocuSigned by:

Josie Holt
 3582E210C4054DA...

Josie Holt

Technical & Quality Manager

Fourth Way,
 Avonmouth,
 Bristol,
 BS11 8TB
 United Kingdom

Commercial Manager/ Importer

42 North Point
 Business Park
 New Mallow Road
 Cork
 Ireland

Commercial Manager/ Responsible Supplier

15 Bagdally Road,
 Campbelltown
 NSW 2560



VOGUE

GD232-A_A5_v2_20201201