
IF3500S PARTS LIST

Item		FHE Part Code	Description
1		IF3500S-CBB	Back of the Control Box
2*		IF3500S-TO	Thermal Overload WQS-230-0030 16A 125/250V
3		IF3500S-CPCW	Control Panel Connect Wire:
4*		IF3500S-CPG	Control Panel Glass
5		IF3500S-CB	Control Box
6*	Version 1	IF3500S-OTS	Oil Temperature Sensor
	Version 2	IF3500S-OTS-V2	Oil Temperature Sensor
7		IF3500S-Tank	Tank
8		IF3500S-CP	Control Panel
9*		IF3500S-Handle	Handle
10		IF3500S-Lid	Lid
11*		IF3500S-SFS	Fixed Support for Sensor
12*		IF3500S-FS	Filter Screen
13*		IF3500S-Basket	Basket
14		IF3500S-TFS	Tubing Fixing Sheet
15		IF3500S-TC	Tap Cover
16		IF3500S-Tap	Tap
17		IF3500S-SSH	Stainless Steel Housing
18*		IF3500S-EPT	Equal Potential Terminal
19*		IF3500S-IG	Inside Glassplate
20		IF3500S-TCW	Thermostat Connect Wire
21*		IF3500S-HC	Heating Coil
22		IF3500S-Spring	Spring
23*		IF3500S-FM	Fan Motor
24*		IF3500S-Sensor-11A	11A Sensor
25*		IF3500S-PCB	PCB Control Board
26		IF3500S-EW	Earth Wire
27		IF3500S-IPH	Inside Plastic Housing

IF3500S EXPLODED DIAGRAM

Item		FHE Part Code	Description
28		IF3500S-PCL	Plug Cord Lock
29		IF3500S-PC	Plug Cord
30		IF3500S-PCF	Plug Cord Fixing
31		IF3500S-BP	Bottom Plate
32		IF3500S-Feet	Feet/Foot
		S13	Stainless Steel Pasta Basket With Wooden Hook Handle
		IF3500S-DTA	Drain Tap Assembly

*Wearable parts