





Pre-Installation Checklist

3 GROUP MACHINE


	Plumber	Electrician	Shopfitter/ Builder	Coffee Technician
☐ Mains pressure 3-7 bars - Cold water tap with 350kpa Pressure limiting valve (350kpa PLV) with 10mm male connection - within 1000mm	✓	✗	✓	✗
☐ ≥50mm S-trap waste point under the machine - within 1000mm	✓	✗	✓	✗
☐ ≥50mm hole saw bench - directly under where machine position	✗	✗	✓	✗
☐ 32amp 3 pin outlet - within 1000mm of machine	✗	✓	✓	✗
☐ 32amp plug on coffee machine	✗	✓	✓	✗
OR				
☐ 32amp hard wired - within 1000mm of machine	✗	✓	✓	✗




V380-415/3+N
THREE-PHASE
삼상 별
CONNECTION WITH
NEUTRAL
중성과의 연결



V220-240/3
THREE-PHASE
삼상 델타
CONNECTION
연결



V220-240/2
SINGLE-PHASE
단일 위상
CONNECTION
연결



V220-240/2
SINGLE-PHASE
단일 위상
CONNECTION
연결

(0) Blu (Neutral) (0) 블루 (우중중한)	(0) Blu (Neutral) (0) 블루 (우중중한)	(0) Blu (Neutral) (0) 블루 (우중중한)	(0) Blu (Neutral) (0) 블루 (우중중한) (0) White (neutral for USA)
(1) Brown (1) 갈색	(1) Brown + (3) Grey (1) 갈색 + (3) 회색	(1) Brown + (2) Black + (3) Grey (1) 갈색 + (2) 검은 (3) 회색	(1) Brown (1) 갈색 + (1) Black for USA
(2) Black, (2) 검은	(2) Black, (2) 검은		
(3) Grey, (3) 회색			
(3P+N+T)	(3P+T)	(1P+N+T)	(1P+N+T)
380-415 Vac; 50-60 Hz	220-240 Vac; 50-60 Hz	220-240 Vac; 50-60 Hz	220-240 Vac; 50-60 Hz



Installation Guide

MACHINE INSTALLATION CHECKLIST

	Coffee Technician	Plumber	Electrician	Shopfitter/Builder
☐ Machine positioning	✓	✓	✓	✓
☐ Machine connections to water / power / waste line	✓	✗	✗	✗
☐ Water filtration Installation	✓	✓	✗	✓
☐ Boiler fill and power function	✓	✗	✗	✗
☐ Bench testing	✓	✗	✗	✗
☐ Steam pressure adjustments	✓	✗	✗	✗
☐ Water pressure adjustment	✓	✗	✗	✗
☐ Volumetric programming	✓	✗	✗	✗

Book your Installation with a Coffee Technician – visit bzau.com.au

The above information and advice is general in nature. If you are unsure of any part of the installation, speak to a registered Bezzera Australia Coffee Technician today.