



PRODUCT DOCUMENT PACK

Prepared and distributed by KW Commercial Kitchen

PRODUCT

Apuro FU139-A Digital Planetary Mixer – 30L, 1.5kW

Model / SKU: FU139-A

KW COMMERCIAL KITCHEN

7/72 Canterbury Road, Bankstown NSW 2200

Phone 1300 001 366

Email sales@kwcommercial.com.au

Web www.kwcommercial.com.au




Scan for the current KW product page

DOCUMENT NOTICE

The supplier document begins on the next page. KW contact branding is added in a separate footer area and does not replace the supplier's instructions, specifications or warranty terms.

Official supplier source: <https://media.nisbets.com/asset/au/media/exploded%20diagram%20fu139a.pdf>



Machine	Explode	Code	Description
FU139-A Apuro 30Ltr Digital Planetary Mixer	1	AF500	Spiral Dough
FU139-A Apuro 30Ltr Digital Planetary Mixer	2	AF501	Hook Flat Beater
FU139-A Apuro 30Ltr Digital Planetary Mixer	3	AF502	Wire Whip
FU139-A Apuro 30Ltr Digital Planetary Mixer	4	AU448	Guard Ring
FU139-A Apuro 30Ltr Digital Planetary Mixer	5	AS084	Back Safety Guard
FU139-A Apuro 30Ltr Digital Planetary Mixer	6	AS087	Micro Switch Prod
FU139-A Apuro 30Ltr Digital Planetary Mixer	7		Block
FU139-A Apuro 30Ltr Digital Planetary Mixer	8		Arrow Block
FU139-A Apuro 30Ltr Digital Planetary Mixer	9		Guard Moving Ring
FU139-A Apuro 30Ltr Digital Planetary Mixer	10		Front Safety Guard
FU139-A Apuro 30Ltr Digital Planetary Mixer	11	AF504	Bowl
FU139-A Apuro 30Ltr Digital Planetary Mixer	12		Nut
FU139-A Apuro 30Ltr Digital Planetary Mixer	13		Compression Spring
FU139-A Apuro 30Ltr Digital Planetary Mixer	14		Pressing Plate
FU139-A Apuro 30Ltr Digital Planetary Mixer	15	AS090	Circlip
FU139-A Apuro 30Ltr Digital Planetary Mixer	16		Circlip
FU139-A Apuro 30Ltr Digital Planetary Mixer	17		Main Shaft Cover - AN727
FU139-A Apuro 30Ltr Digital Planetary Mixer	18		Plug Cover - AN520
FU139-A Apuro 30Ltr Digital Planetary Mixer	19		Transmission Support
FU139-A Apuro 30Ltr Digital Planetary Mixer	20		Bearing
FU139-A Apuro 30Ltr Digital Planetary Mixer	24	AS093	Main Shaft
FU139-A Apuro 30Ltr Digital Planetary Mixer	25		Key
FU139-A Apuro 30Ltr Digital Planetary Mixer	26		Key
FU139-A Apuro 30Ltr Digital Planetary Mixer	27		Gear
FU139-A Apuro 30Ltr Digital Planetary Mixer	28		Washer
FU139-A Apuro 30Ltr Digital Planetary Mixer	29		Bearing
FU139-A Apuro 30Ltr Digital Planetary Mixer	30	AN728	Bushing
FU139-A Apuro 30Ltr Digital Planetary Mixer	31	AS096	Oil Seal
FU139-A Apuro 30Ltr Digital Planetary Mixer	32	AS099	Nut
FU139-A Apuro 30Ltr Digital Planetary Mixer	33	AS102	Spring
FU139-A Apuro 30Ltr Digital Planetary Mixer	34	AS103	Pressure Plate
FU139-A Apuro 30Ltr Digital Planetary Mixer	35	AS106	Bearing
FU139-A Apuro 30Ltr Digital Planetary Mixer	36		Gear Shaft
FU139-A Apuro 30Ltr Digital Planetary Mixer	37		Key
FU139-A Apuro 30Ltr Digital Planetary Mixer	38		Gear
FU139-A Apuro 30Ltr Digital Planetary Mixer	39		Bush
FU139-A Apuro 30Ltr Digital Planetary Mixer	40		Gear
FU139-A Apuro 30Ltr Digital Planetary Mixer	41		Washer
FU139-A Apuro 30Ltr Digital Planetary Mixer	42		Retainer Ring
FU139-A Apuro 30Ltr Digital Planetary Mixer	43	AN741	Cover
FU139-A Apuro 30Ltr Digital Planetary Mixer	44		Nut
FU139-A Apuro 30Ltr Digital Planetary Mixer	45		Spring Washer

Machine	Explode	Code	Description
FU139-A Apuro 30Ltr Digital Planetary Mixer	46	AS110	Bearing
FU139-A Apuro 30Ltr Digital Planetary Mixer	47		Circlip
FU139-A Apuro 30Ltr Digital Planetary Mixer	48		Worm Shaft Gear
FU139-A Apuro 30Ltr Digital Planetary Mixer	49		Worm Shaft
FU139-A Apuro 30Ltr Digital Planetary Mixer	50		Worm Wheel - AN656
FU139-A Apuro 30Ltr Digital Planetary Mixer	51		Circlip
FU139-A Apuro 30Ltr Digital Planetary Mixer	52		Circlip
FU139-A Apuro 30Ltr Digital Planetary Mixer	53	AN747	Worm Shaft Gear Cover
FU139-A Apuro 30Ltr Digital Planetary Mixer	54	AS128	Fan
FU139-A Apuro 30Ltr Digital Planetary Mixer	55	AS113	Motor(With Tool)
FU139-A Apuro 30Ltr Digital Planetary Mixer	56		Oil Seal
FU139-A Apuro 30Ltr Digital Planetary Mixer	57		Worm Wheel - AF476
FU139-A Apuro 30Ltr Digital Planetary Mixer	58		Retainer Ring
FU139-A Apuro 30Ltr Digital Planetary Mixer	59		Gear Box
FU139-A Apuro 30Ltr Digital Planetary Mixer	60	AS115	Hood
FU139-A Apuro 30Ltr Digital Planetary Mixer	61		Motor Box
FU139-A Apuro 30Ltr Digital Planetary Mixer	62	AL822	Rear Panel
FU139-A Apuro 30Ltr Digital Planetary Mixer	63	AS119	Motor PCB
FU139-A Apuro 30Ltr Digital Planetary Mixer	64	AS122	Control PCB
FU139-A Apuro 30Ltr Digital Planetary Mixer	65	AS125	Control Panel
FU139-A Apuro 30Ltr Digital Planetary Mixer	73	AS132	Retainer Ring
FU139-A Apuro 30Ltr Digital Planetary Mixer	74		Planetary Gear - AN974
FU139-A Apuro 30Ltr Digital Planetary Mixer	75		Bearing
FU139-A Apuro 30Ltr Digital Planetary Mixer	76		Oil Seal
FU139-A Apuro 30Ltr Digital Planetary Mixer	77		Key
FU139-A Apuro 30Ltr Digital Planetary Mixer	78		Working Shaft - AM173
FU139-A Apuro 30Ltr Digital Planetary Mixer	79		Pin - AF536
FU139-A Apuro 30Ltr Digital Planetary Mixer	81		Running Plate - AN721
FU139-A Apuro 30Ltr Digital Planetary Mixer	80	AS138	Inner Gear
FU139-A Apuro 30Ltr Digital Planetary Mixer	82	AN730	Large Washer
FU139-A Apuro 30Ltr Digital Planetary Mixer	83		Nut
FU139-A Apuro 30Ltr Digital Planetary Mixer	84		Handle Fixing Set
FU139-A Apuro 30Ltr Digital Planetary Mixer	85		Press Plate
FU139-A Apuro 30Ltr Digital Planetary Mixer	86		Bowl Left Press Plate
FU139-A Apuro 30Ltr Digital Planetary Mixer	87	AS142	Bowl Locating Pin
FU139-A Apuro 30Ltr Digital Planetary Mixer	88	AT254	Support
FU139-A Apuro 30Ltr Digital Planetary Mixer	89		Nut
FU139-A Apuro 30Ltr Digital Planetary Mixer	90		Spring
FU139-A Apuro 30Ltr Digital Planetary Mixer	91		Flat Washer
FU139-A Apuro 30Ltr Digital Planetary Mixer	92	AS148	Proximity Switch
FU139-A Apuro 30Ltr Digital Planetary Mixer	93	AS150	Proximity Switch Installing Box
FU139-A Apuro 30Ltr Digital Planetary Mixer	94		Guide Right Press Plate
FU139-A Apuro 30Ltr Digital Planetary Mixer	95		Guide Left Press Plate
FU139-A Apuro 30Ltr Digital Planetary Mixer	96		Pillar

Machine	Explode	Code	Description
FU139-A Apuro 30Ltr Digital Planetary Mixer	97		Bowl Right Press Plate
FU139-A Apuro 30Ltr Digital Planetary Mixer	98		Hiding Plate
FU139-A Apuro 30Ltr Digital Planetary Mixer	99		Case
FU139-A Apuro 30Ltr Digital Planetary Mixer	100	AS145	Front Rubber Feet - AH068
FU139-A Apuro 30Ltr Digital Planetary Mixer	101		Back Rubber Feet
FU139-A Apuro 30Ltr Digital Planetary Mixer	102		Pin
FU139-A Apuro 30Ltr Digital Planetary Mixer	103	AP030	Connecting Rod
FU139-A Apuro 30Ltr Digital Planetary Mixer	104		Pin
FU139-A Apuro 30Ltr Digital Planetary Mixer	105		Flat Washer
FU139-A Apuro 30Ltr Digital Planetary Mixer	106	AP514	Compression Spring
FU139-A Apuro 30Ltr Digital Planetary Mixer	107		Nut
FU139-A Apuro 30Ltr Digital Planetary Mixer	108	AF481	Crank Lever
FU139-A Apuro 30Ltr Digital Planetary Mixer	109	AS153	Handle-Shifter
FU139-A Apuro 30Ltr Digital Planetary Mixer	110		Handle
FU139-A Apuro 30Ltr Digital Planetary Mixer	111		Pin
FU139-A Apuro 30Ltr Digital Planetary Mixer	112		Pin
FU139-A Apuro 30Ltr Digital Planetary Mixer	113		Pillar Back Cover
FU139-A Apuro 30Ltr Digital Planetary Mixer	114		Electrical Box Back Cover
FU139-A Apuro 30Ltr Digital Planetary Mixer	115	AF315	Gland
FU139-A Apuro 30Ltr Digital Planetary Mixer	116		Micro Switch Fixing Plate
FU139-A Apuro 30Ltr Digital Planetary Mixer	117	AS156	Micro Switch
FU139-A Apuro 30Ltr Digital Planetary Mixer	118		AUS Power Cord