



PRODUCT DOCUMENT PACK

Prepared and distributed by KW Commercial Kitchen

PRODUCT

FED DH-PACK Clear Wash & Rinse Aid 2 × 2L Pack

Model / SKU: DH-PACK

KW COMMERCIAL KITCHEN

7/72 Canterbury Road, Bankstown NSW 2200

Phone 1300 001 366

Email sales@kwcommercial.com.au

Web www.kwcommercial.com.au



Scan for the current KW product page

DOCUMENT NOTICE

The supplier document begins on the next page. KW contact branding is added in a separate footer area and does not replace the supplier's instructions, specifications or warranty terms.

Official supplier source: https://www.foodequipment.com.au/md_productpdf/index/generate/product/8616/store/7/



DISHWASHER CHEMICAL CLEANING PACK (Clear Wash 2L + Rinse Aid 2L) - DH-PACK

Quick Overview

Clear Wash

- Preparation: Rinse off excess food scraps from plates and cutlery before loading them into the dishwasher.
- Usage: Insert the tube from the dishwashing unit into the open bottle of Clear Wash. If dispensing adjustments are necessary, refer to the user instruction manual.
- Optimal Performance: Ensure the dishwasher's pH is at the manufacturer's recommendation. If the machine water is heavily soiled, drain and refill with clean water to maintain effective cleaning.

Rinse Aid

Rinse Aid should be installed properly and used with the installed dispenser on your dishwashing machine. Refer to your dishwasher's user manual for correct dispensing settings.

- Recommended Use: Best paired with Clear Wash (Machine Dish Wash Liquid) or Chlorinated Dish Wash Machine Liquid.

Description

DISHWASHER PACK (Clear Wash 2L + Rinse Aid 2L) - DH-PACK

Clear Wash

This concentrated alkaline solution is tailored for commercial dishwashing machines. It tackles stubborn stains, grease, dirt, and food residues with ease. The built-in descaler enhances machine performance, ensuring dishes, glasses, and cutlery are left sparkling clean and free of water spots.

Rinse Aid

Specially formulated for the final rinse cycle of commercial dishwashing machines, Rinse Aid enhances drying performance. It eliminates spots, residues, and moisture, leaving dishes, glasses, and cutlery streak-free and brilliantly polished for a professional finish.

Clear Wash

- Preparation: Rinse off excess food scraps from plates and cutlery before loading them into the dishwasher.
- Usage: Insert the tube from the dishwashing unit into the open bottle of Clear Wash. If dispensing adjustments are necessary, refer to the user instruction manual.
- Optimal Performance: Ensure the dishwasher's pH is at the manufacturer ' s recommendation. If the machine water is heavily soiled, drain and refill with clean water to maintain effective cleaning.

Rinse Aid

Rinse Aid should be installed properly and used with the installed dispenser on your dishwashing machine. Refer to your dishwasher's user manual for correct dispensing settings.

- Recommended Use: Best paired with Clear Wash (Machine Dish Wash Liquid) or Chlorinated Dish Wash Machine Liquid.

Your Shipping Specifications

Product Condition	New
-------------------	-----