


FW6L-122 EXPLODED DIAGRAM



FW6L-122 PARTS LIST

Item	FHE Part Code	Description	QTY
1		Flat Head Rivet Nut M8	8
2		Hexagon Nut	1
3		Ground Wire Mark	1
4		Rivet Ø4	24
5		Round Head Crossing Screw M4x16	6
6	FW6L-122-LP	Lower Plate	2
7	FW4L-092-LBMP	Lamp Bracket Mounting Plate	6
8	FW6L-122-TIC	Thermal Insulating Cotton	1
9	FW6L-122-TCP	Top Cover Plate	2
10	FW4L-092-FCT	Female Crimp Terminal FRD2-156	2
11	FW4L-092-CESC	Closed End Splice Connector CE-2	17
12	FW4L-092-MCT	Male Crimp Terminal FRD2-156	2
13	FW4L-092-HTRW	High-Temperature Red Wire 1.5mm ²	1
14	FW4L-092-HTBW	High-Temperature Blue Wire 1.5mm ²	1
15		Ground Wire Mark 0.55m	1
16	FW4L-092-TTLUP	Two-tier Left Upright Post 650mm X 38mm	3
17*	FW4L-092-HL	Halogen Lamp	6
18		White Triangular Flat-Head Screw M4x8	44
19	FW4L-092-LS	Lamp Shade 1210	6
20	FW4L-092-HLF	Halogen Lamp Fitting	6
21	FW6L-122-CP	Cover Plate	2
22	FW4L-092-BSB	Bottom Support Beam 300mm X 38mm	2
23	FW4L-092-TTRUP	Two-tier Right Upright Post 650mm X 38mm	1
24	FW4L-092-PCC	Power Cord Clamp	1
25*	FW4L-092-PC	Power Cord	1
26*	FW4L-092-Switch	Switch (Power button)	2
27	FW4L-092-STEC	Square Tube End Cap	4
28		Hexagon Socket Flat-Head Screw M8x50	8
29*	FW4L-092-RPIL	Red Power Indicator Light	2

*Wearable parts