



## PRODUCT DOCUMENT PACK

Prepared and distributed by KW Commercial Kitchen

### PRODUCT

# Apuro GJ459-A Bag Sealer - 300mm

**Model / SKU: GJ459-A**


#### KW COMMERCIAL KITCHEN

7/72 Canterbury Road, Bankstown NSW 2200

Phone 1300 001 366

Email [sales@kwcommercial.com.au](mailto:sales@kwcommercial.com.au)

Web [www.kwcommercial.com.au](http://www.kwcommercial.com.au)



Scan for the current KW product page

### DOCUMENT NOTICE

The supplier document begins on the next page. KW contact branding is added in a separate footer area and does not replace the supplier's instructions, specifications or warranty terms.

Official supplier source: <https://media.nisbets.com/asset/au/media/user%20manual%20gj459a.pdf>

# apuro

## Bag Sealer

### Instruction manual



**Model:  
GJ459-A**

## Safety Instructions

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components on this product.
- Consult Local and National Standards to comply with the following:
  - Health and Safety at Work Legislation
  - Fire Precautions
  - Wiring Regulations
  - Building Regulations
- DO NOT immerse the appliance in water.
- The sealing bar becomes hot during use. DO NOT touch the sealing bar during or immediately after operation.
- Do not use the appliance for anything other than its intended use.
- Always switch off and disconnect the power supply to the appliance when not in use.
- Not suitable for outdoor use.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
- If the power cord is damaged, it must be replaced by an APURO agent or a recommended qualified technician in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep the sealing surface clean.

- APURO recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.

## Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your APURO product.

## Pack Contents

The following is included:

- APURO Bag Sealer
- Instruction manual

APURO prides itself on quality and service, ensuring that at the time of unpacking the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your APURO dealer immediately.

## Controls



## Operation

Plug in the appliance. The machine is now ready for use.

1. Place the open end of the bag across the Sealing Bar.
2. Press the Handle down firmly. Indicator light will turn red. Keep the handle being pressed down.
3. When sealing is complete indicator light will turn off. Bag should now be sealed.
4. Remove bag and inspect bag and seal.


**Note: A good seal will look clear upon inspection. If the seal is spotty, incomplete, wrinkled, white or milky, adjust timer knob and reseal.**

## Cleaning, Care & Maintenance

- Always allow to cool before cleaning.
- Disconnect from Power Supply.
- Do not wipe the sealing surface with a wet cloth. Use a soft cloth dampened with alcohol instead.
- Dry thoroughly after cleaning.
- **Caution: Do not allow any water to spill into the appliance when cleaning.**


### Spare part AD578: Apuro Heating Element and Teflon Tape

Tool required: Phillips screwdriver, tweezers (not included)



#### Replace the tape


1. Use the screwdriver to remove the screws fixing the cover plate of heating element, then remove the cover plate.



2. Remove the tape, clean the heating element with a soft cloth dampened with alcohol.
3. Attach a new tape and install back the cover plate of heating element. Press the tape and tighten the screws.

#### Replace the heating element

1. Follow the steps above to remove the cover plate and tape.
2. Remove the screws fixing the heating element, then remove the heating element.



3. Install a new heating element, and make sure it is centred.

## Troubleshooting

A qualified technician must carry out repairs if required.

| Fault                          | Probable Cause                          | Solution                                                                        |
|--------------------------------|-----------------------------------------|---------------------------------------------------------------------------------|
| The appliance is not working   | The unit is not switched on             | Check unit is plugged in correctly and switched on                              |
|                                | Plug or lead is damaged                 | Replace plug or lead                                                            |
|                                | Mains power supply fault                | Check mains power supply                                                        |
| Bags are not sealing correctly | Moisture in bag under the sealing bar   | Ensure inside of the bag is dry and free from moisture where it is to be sealed |
|                                | End of bag not placed above sealing bar | Move end of bag over sealing bar                                                |

## Technical Specifications

Note: Due to our continuous improvement process, the product specifications are subject to change without notice.

| Model   | Voltage        | Power | Current | Max Sealing Length | Dimensions h x w x d mm | Net Weight (kg) |
|---------|----------------|-------|---------|--------------------|-------------------------|-----------------|
| GJ459-A | 220-240V~ 50Hz | 260W  | 1.1A    | 305mm              | 235 x 430 x 85          | 2.85            |

## Electrical Wiring

The plug is to be connected to a suitable mains socket.

This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed.



If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

## Compliance

The product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.

APURO parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

APURO products have been approved to carry the following symbol:



**All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of APURO.**  
**Every effort is made to ensure all details are correct at the time of going to press, however, APURO reserve the right to change specifications without notice.**

DECLARATION OF CONFORMITY

• Conformiteitsverklaring • Déclaration de conformité • Konformitätserklärung • Dichiarazione di conformità •  
• Declaración de conformidad • Declaração de conformidade

|                                                                                                                                                                                                                                                                                                              |  |                                                                                                                                                                                                                                                                |  |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| Equipment Type • Uitrustingstype • Type d'équipement • Gerätetyp<br>• Tipo di apparecchiatura • Tipo de equipo • Tipo de equipamento                                                                                                                                                                         |  | Model • Modèle • Modell • Modello<br>• Modelo • Malli                                                                                                                                                                                                          |  |
| Bag Sealer – 300mm                                                                                                                                                                                                                                                                                           |  | GJ459 -A                                                                                                                                                                                                                                                       |  |
| Application of Territory Legislation & Council Directives(s)<br>Toepassing van Europese Richtlijn(en) • Application de la/des directive(s) du Conseil • Anwendbare EU-Richtlinie(n) • Applicazione delle Direttive<br>• Aplicación de la(s) directiva(s) del consejo • Aplicação de directiva(s) do Conselho |  | Electrical safety<br>IEC 60335-1:2010 +A1:2013 +A2:2016<br>IEC 60335-2-45:2002 +A1:2008 +A2:2011<br>EN 62233:2008<br><br>Electro-Magnetic Compatibility<br>EN 55014-1:2017 +A11:2020<br>EN 55014-2:2015<br>EN IEC 61000-3-2:2020<br>EN 61000-3-3:2013 +A1:2019 |  |
| Manufacturer Name • Naam fabrikant • Nom du producteur • Name des Herstellers<br>• Nome del produttore • Nombre del fabricante • Nome do fabricante                                                                                                                                                          |  | Apuro                                                                                                                                                                                                                                                          |  |

I, the undersigned, hereby declare that the equipment specified above conforms to the above Territory Legislation, Directive(s) and Standard(s).

Ik, de ondergetekende, verklaar hierbij dat de hierboven gespecificeerde uitrusting goedgekeurd is volgens de bovenstaande Richtlijn(en) en Standaard(en).

Je soussigné, confirme la conformité de l'équipement cité dans la présente à la / aux Directive(s) et Norme(s) ci-dessus

Ich, der/die Unterzeichnende, erkläre hiermit, dass das oben angegebene Gerät der/den oben angeführten Richtlinie(n) und Norm(en) entspricht.

Il sottoscritto dichiara che l'apparecchiatura di sopra specificata è conforme alle Direttive e agli Standard sopra riportati.

El abajo firmante declara por la presente que el equipo arriba especificado está en conformidad con la(s) directiva(s) y estándar(es) arriba mencionadas.

Eu, o abaixo-assinado, declaro que o equipamento anteriormente especificado está em conformidade com a(s) anterior(es) Directiva(s) e Norma(s)

Date • Data • Date • Datum • Data •  
Fecha • Data

Signature • Handtekening • Signature  
• Unterschrift Firma • Firma •  
Assinatura

Full Name • Volledige naam • Nom et prénom • Vollständiger Name • Nome completo • Nombre completo • Nome por extenso

Position • Functie • Fonction • Position  
• Qualifica • Posición • Função

Manufacturer Address • Adres fabrikant  
• Adresse du fabricant • Adresse des Herstellers • Indirizzo del fabbricante • Dirección del fabricante

|                                                               |                                                                 |
|---------------------------------------------------------------|-----------------------------------------------------------------|
| 9 <sup>th</sup> August 2021                                   |                                                                 |
| DocuSigned by:<br><i>Ashley Hooper</i><br>B39382C9FD9C478...  | DocuSigned by:<br><i>Brendan Denmeade</i><br>D052C5837EB7465... |
| Ashley Hooper                                                 | Brendan Denmeade                                                |
| Group Head of Product Quality & Compliance                    | Commercial Manager/<br>Responsible Supplier                     |
| Fourth Way, Avonmouth,<br>Bristol, BS11 8TB<br>United Kingdom | 15 Badgally Road,<br>Campbelltown NSW 2560                      |



**apuro**

GJ459-A\_A5\_v3\_2025/04/28