

Wine Fridge

Instruction manual



Model:

GM627-A/GM628-A/GM629-A/GM888-A/GM889-A

(EN)

Safety Instructions

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components or service panels on this product.

- In Queensland the service agent/qualified technician MUST hold a Gas Work Authorisation or License for hydrocarbon refrigerants if the appliance gas system is being opened or charged.

- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - Fire Precautions
 - IEE Wiring Regulations
 - Building Regulations
- DO NOT immerse in water, or use steam/jet washers to clean the unit.
- DO NOT cover the appliance when it is operating.
- DO NOT store food in the wine fridge.
- Always carry, store and handle the appliance in a vertical position.
- Never tilt the appliance more than 45° from the vertical.
- This appliance is intended to be used in household and similar applications.
- Keep all packaging away from children. Dispose of the packaging in accordance with the regulations of local authorities.
- If the power cord is damaged, it must be replaced by a POLAR agent or a recommended qualified technician in order to avoid a hazard.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

2

- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- POLAR recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.
- This appliance is intended to be used exclusively for the storage of wine.
- Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances.

Warning: Risk of Fire / flammable materials

- The refrigerant gas contained in this appliance is isobutene (R600a), which is low-polluting but flammable.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.



Warning: Keep all ventilation openings clear of obstruction. Unit should not be boxed in without adequate ventilation.

- To comply with AS/NZS 60079.10.1:2009: Ensure there are not sources of ignition in any area where refrigerant could gather in the event of a leak.
- Electrical equipment should not be placed under the vent or where refrigerant could gather in the event of a leak.
- **Warning:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- **Warning:** Do not damage the refrigerant circuit.
- Warning: Do not use electrical appliances inside the food storage compartments of the appliance.



(EN)

GM627-A_GM628-A_GM629-A_GM888-A_GM889-A_ML_A5_v1_20240925.indb 3

3

Telephone Helpline: 1300225960

(EN)

Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your POLAR product.

Pack Contents

The following is included:

• Wine fridge

Instruction manual

• Door Handle assembly

POLAR prides itself on quality and service, ensuring that at the time of unpacking the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your POLAR dealer immediately.

Installation

Note: Not for use in vans or trailers, food trucks or similar vehicles.

Note: If the unit has not been stored or moved in an upright position, let it stand upright for approximately 12 hours before operation. If in doubt allow to stand.

- 1. Place the fridge on a floor that is able to support it once fully loaded.
- 2. Remove the appliance from the packaging and the protective film from all surfaces.
- 3. Avoid positioning the fridge in direct sunlight or damp areas.
- 4. To optimize performance and longevity, ensure a minimum clearance of 2.5cm is maintained between the unit and walls and other objects, with a minimum 20cm clearance on the top. **NEVER LOCATE NEXT TO A HEAT SOURCE.**
- 5. If necessary, adjust the screw legs of the fridge to make it level.



WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged.

WARNING: Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.

6. **Installing the Door handle:** Remove the door gasket covering the handle location - there are two designated holes for the handle installation. Attach the handle and fix with the screws provided. Replace the door gasket into place.

Operation

Note: the fridge should be placed in an area where the ambient temperature is between 16-38°C.

- When using the fridge for the first time, or re-starting it after a long period of time, there may be a few degrees variance between the selected temperature and what is shown on the LED display. Once the fridge has been switched on for a few hours, this should rectify itself.
- If the unit is unplugged, has lost power or been turned off, wait 30 minutes to 2 hours before
 restarting the appliance.

4

Control panel



Power	Press to turn the system on/off		
Light	Press to turn the inner light on/off		
Up	 Press to increase / decrease the temperature (Temperature range: 5-20°C / 41-68°F) 		
Down	 Press and hold both buttons for 5 seconds to switch between Fahrenheit (°F) and Celsius (°C) 		

- When storing mainly red wine, the recommended temperature is 14-18°C.
- When storing mainly white wine, the recommended temperature is 8-12°C.
- When storing mainly sparkling wine, the recommended temperature is 7-9°C.

Note for the single-zone wine fridge (GM627-A/GM888-A/GM889-A): To achieve the required temperature, the set point temperature must always be lower than the ambient temperature.


Note for the dual-zone wine fridges (GM628-A and GM629-A):

- The temperature for the lower zone must ALWAYS be the same or higher than the upper zone.
- The lower zone is featured with heating function, which will turn on automatically when the set temperature is higher than the room temperature or the actual lower zone temperature.

Storage

GM627-A:

36 wine bottles can be placed in the upper shelves -9 bottles on each. A maximum of 15 bottles can be stored on the bottom when the bottom shelf is removed.



(EN)

))][(

))]((

))][(


(0)(0)

 (\mathbf{O})

(EN)

GM628-A:

90 wine bottles can be placed in the upper and lower shelves - 9 bottles on each. A maximum of 36 bottles can be stored on the bottom and top when the bottom and top shelves are removed.



GM629-A:

154 wine bottles can be placed in the upper and lower shelves - 11 bottles on each. A maximum of 26 bottles can be stored on the bottom when the bottom shelf is removed.

Note:


Bottle capacities are approximate maximums when storing traditional Bordeaux 750ml bottles and include bulk storage.

When using thicker bottles, it may be necessary to remove shelves and double stack bottles to maximise storage.

To prevent damage to the door gasket, ensure the door is fully open when pulling shelves out of the rail compartment.


GM888-A:

81 wine bottles can be placed in the upper shelves - 9 bottles on each. A maximum of 56 (34+22) bottles can be stored on the lower parts when the lower shelves are removed.



GM889-A:

165 wine bottles can be placed in the upper shelves - 11 bottles on each. A maximum of 27 bottles can be stored on the bottom when the bottom shelf is removed.



(EN)

To avoid contamination of drink, please respect the following instructions:

- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- If the refrigerating appliance is left empty for long periods, switch it off. Then defrost and clean it thoroughly. Let it dry well and leave the door open to prevent mould developing within the appliance.
- Clean regularly surfaces that can come in contact with drink and accessible drainage systems.
- Only load the appliance when it has reached the correct operating temperature.

Cleaning, Care & Maintenance

- Always switch off and disconnect the power supply before cleaning.
- Remove all bottles from the appliance.
- Warm, soapy water is recommended for cleaning. Cleaning agents may leave harmful residues.
- Periodically clean the bottom of the wine fridge compartment to remove any build-up of condensation.

Defrosting

The unit has an automatic defrost cycle to reduce the build-up of ice, but occasionally a manual defrost may be necessary. To manually defrost the appliance remove contents and switch off unit. Allow ice to melt and dry cabinet before switching back on.

Troubleshooting

A qualified technician must carry out repairs if required.

Fault	Probable Cause	Solution	
The appliance is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on	
	Plug or lead is damaged	Replace plug or lead	
	Mains power supply fault	Check mains power supply	
Appliance is noisy or works intermittently	Appliance is not level	Adjust the feet to level the appliance	
Wine fridge cabinet is	Temperature set incorrectly	Check temperature and reset if necessary	
not cold enough	External environment may require colder temperature	Check temperature and reset if necessary	
	The door is opened too often	Only open when necessary	
	Door seal is worn	Consult a qualified technician	
Light is not working	Light key is not pressed	Press the light key	
	Bulb has blown	Consult a qualified technician	
Door will not close	Appliance is not level	Adjust the feet to level the appliance	
properly	Shelves are out of position	Check all shelves are properly inserted	
	Door seal is dirty	Wipe clean with a damp cloth	
Condensation on outer surfaces (glass)	Condensation may occur when the humidity is high and water particles in the air contact with cold surfaces. This is normal, just wipe away with a dry cloth		

Technical Specifications

Note: Due to our continuous improvement process, the product specifications are subject to change without notice.

Model	Voltage	Power	Current	Bottle Capacity	Refrigerant	Temp. Range	Dimensions H x W x D mm	Weight (kg)
GM627-A	220-240V~ 50Hz	150W	1.5A	51	R600a 45g	5-20°C	820 x 595 x 625	50.00
GM628-A		150W	1.5A	126	R600a 45g	5-20°C	1575 x 595 x 685	102.00
GM629-A		150W	1.5A	180	R600a 45g	5-20°C	1850 x 595 x 760	112.00
GM888-A		150W	1.5A	137	R600a 45g	5-20°C	1575 x 595 x 685	89.00
GM889-A		150W	1.5A	192	R600a 45g	5-20°C	1850 x 595 x 760	106.00

Model	Suitable ambient temperature
GM627-A/GM628-A/GM629-A/GM888-A/ GM889-A	+16°C ~ +38°C

Electrical Wiring

The plug is to be connected to a suitable mains socket.

This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

The appliances must be earthed.

If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Compliance

The product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.

POLAR parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

POLAR products have been approved to carry the following symbol:

All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of POLAR. Every effort is made to ensure all details are correct at the time of going to press, however, POLAR reserve the right to change specifications without notice.







DECLARATION OF CONFORMITY

• Conformiteitsverklaring • Déclaration de conformité • Konformitätserklärung • Dichiarazione di conformità •

Declaración de conformidad

Equipment Type • Uitrustingstype •	Type d'équipement • Gerätetyp	Model • Modèle • Modell •
 Tipo di apparecchiatura Tipo de equ 	Modello	
		• Modelo
G-Series Single Zone Wine Fridge Stainless Steel 137 G-Series Single Zone Wine Fridge Stainless Steel 126 G-Series Dual Zone Wine Fridge Stainless Steel - 126 G-Series Dual Zone Wine Fridge Stainless Steel - 126 G-Series Double Door Beer/Wine Fridge Application of Territory Legislation & Council Directives(s) Toepassing van Europese Richtlijn(en) • Application de la/des directive(s) du Conseil • Anwendbare EU-Richtlinie(n) • Applicazione delle Direttive • Aplicación de la(s) directiva(s) del consejo	bottles Bottles bottles Low Voltage Directive (LVD) - 2014/35/EU Electrical Equipment (Safety) Regulations 2016 EN 60335-12012 +A11:2014 +A13:2017 +A1:2019 +A14:2019 +A2:2012 +A11:2022 EN 106 0335-2-24:2022 +A11:2022 Electro-Magnetic Compatibility (EMC) Directive 2014/30/EU - recast of 2004/108/EC Electro-Magnetic Compatibility (EMC) Directive 2014/30/EU - recast of 2004/108/EC Electro-Magnetic Compatibility Regulations 2016 (5.1. 2016/1091) EN 55014-1: 2021 EN 15010-3: 2019 +A1:2021 EN 15010-3: 2019 +A1:2021 EN 15010-3: 2019 +A1:2021 EN 55014-1: 2021 EN 15010-3: 2019 +A1:2021 EN 15010-3:	GM888 (-E & -A) GM888 (-E & -A) GM629 (-E & -A) GM629 (-E & -A) GM627 (-E & -A) GL097 (-E & -A) GL097 (-E & -A) Electrical Safety AS/N25 60335-2:24:2021 +A1:2022 AS/N25 60335-2:24:2021 +A1:2021 IEC 60335-1:2020 +A1:2021 IEC 60335-2:24:2020 Electromagnetic Compatibility EN 55014-1: 2021 EN 155014-1: 2021 EN 155014-2: 2021 EN 150100-3:2: 2013 +A1:2019 +A2:2021
	Nom du fabricant Name des Herstellers	Polar
 Nome del fabbricante Nombre del fab 	pricante	

I, the undersigned, hereby declare that the equipment specified above conforms to the above Territory Legislation, Directive(s) and Standard(s).

Ik, de ondergetekende, verklaar hierbij dat de hierboven gespecificeerde uitrusting goedgekeurd is volgens de bovenstaande Richtlijn(en) en Standaard(en).

Je soussigné, confirme la conformité de l'équipement cité dans la présente à la / aux Directive(s) et Norme(s) ci-dessus

Ich, der/die Unterzeichnende, erkläre hiermit, dass das oben angegebene Gerät der/den oben angeführten Richtlinie(n) und Norm(en) entspricht. Il sottoscritto dichiara che l'apparecchiatura di sopra specificata è conforme alle Direttive e agli Standard sopra riportati.

El abajo firmante declara por la presente que el equipo arriba especificado está en conformidad con la(s) directiva(s) y estándar(es) arriba mencionadas.

Date • Data • Date • Datum • Data • Fecha Signature • Handtekening • Signature • Unterschrift Firma • Firma

Full Name • Volledige naam • Nom et prénom • Vollständiger Name • Nome completo • Nombre completo Position • Functie • Fonction • Position • Qualifica • Posición

Manufacturer Address • Adres fabrikant • Adresse du fabricant • Adresse des Herstellers • Indirizzo del fabbricante • Dirección del fabricante



28 th Jun 2024		
Docusigned by: Ashiry Hooper B39382C9FD9C478	DocuSigned by: Eoghan Donnellan D352874F7FAB460	DocuSigned by: Brundan Dunmeade 386FAD00DEFB483
Ashley Hooper	Eoghan Donnellan	Brendan Denmeade
Group Head of Product Quality & Compliance	Commercial Manager/ Importer	Commercial Manager/ Responsible Supplier
Fourth Way, Avonmouth, Bristol,	Unit 9003, Blarney Business Park,	15 Badgally Road, Campbelltown NSW 2560
BS11 8TB United Kingdom	Blarney, Co. Cork Ireland	





GM627-A_GM628-A_GM629-A_GM888-A_GM889-A_ML_A5_v1_2024/09/25

